


Before Beginning, make sure your weapon is unloaded.


LACING INSTRUCTIONS

TOTERS™ come with laces in place in the right and left front pockets. The lacing can be changed to provide the correct fit for a particular gun.


1.. Place hand gun into this area of the adjustable pocket just as you would insert it into a regular holster with trigger guard fully enclosed.



2.. If your handgun fits into the pre-adjusted pocket too loosely, determine which button hole is closest to the front of your gun.



3.. Start lace through button hole nearest gun and thread through 3 or 4 button holes before doubling back on lacing to keep it tight.



4.. After determining proper tension on lacing for best fit, leave the ends of the lace hanging loose behind second layer of fabric.

TOTERS™ are illustrated with gun in pocket, however, gun should be removed while lacing is performed. A ball point pen, pencil, or similar object should be used to push an opening through the button holes so that the lacing can be pushed through easily.
